

## Dr. Tenisz™ - USER'S MANUAL

### Step 1)



1. "Dr. Tenisz" is designed to fold to a compact shape for easier transport and storage. Please follow the quick and simple assembly instructions below to enable your practice to begin!

### Step 2)



1. Fold and close the base-bar hinge.
2. Lower the 'locking pin' into the slot on the hinge.
3. Secure the locking pin by tightening the locking handle against it. (Handle is multi-directional for ease of use)

### Step 3)



1. Ensure both base-bar supports (at extreme ends of base-bar) are rotated so they are at 90 degrees to base-bar section (you may need to loosen knobs to allow this).

### Step 4)



1. Tighten locking knobs to secure base-bar supports.

## Step 5)



1. Elevate the main upright to the required angle.
2. Raise the locking lever to secure in position.
3. **Note: The small travel of this locking action is dependant on the tightness of the nut on the opposite side. This may loosen over a period of time and may require small adjustment.**

## Step 6)



1. Raise or lower the extendable section of the upright to the desired height.
2. Secure height by tightening the locking handle (handle is multi-directional for ease of use)

## Step 7)













1. Remove the hitting bar and chute (bar and hose section) from the box. Illustration shows internal connections for future ball replacement.

## Step 8)



1. Lower the hitting bar into the extendable length of the upright to the desired height.
2. Secure height by tightening knob.

<b>CAUTION</b>	
	<p>PLEASE KEEP PUNCHER OILY AFTER USE TO BE FREE OF RUST.</p>
	<p>DO NOT TEAR OUT STRIP ASSEMBLY BY HAND IT MAY DAMAGE SPRING ASSEMBLY.</p>
	<p>PLEASE INSPECT STRIP ASSEMBLY BEFORE USE. REPLACE IF DAMAGED</p>
	<p>KEEP AWAY FROM PEOPLE, WINDOW, TV. OR FURNITURE TO PREVENT ACCIDENTS.</p>

<p>Forehand</p> 	<p>Backhand</p> 
<p>Half volley</p> 	<p>Wide backhand chop</p> 
<p>Top spin</p> 	<p>Slice</p> 

*Dr. Tenisz™*

## HOW TO REPLACE A BALL

Please follow the quick and simple instructions below so different age groups can benefit from hitting different sizes and colours of ball (Mini Tennis) or to replace worn or damaged balls!

